

Oil-Only MeltBlown Pads #WP100M - 15" x 19", 100 pads/package



MeltBlown Mat Pads quickly absorb oil for effective cleanup of petroleum-based spills on land or water.

- **Fast-Wicking:** Loose stacked-weave design increases surface area on spill. Mat starts wicking on contact to save time in critical situations. Works equally well on land or water — it even floats when fully saturated. Ideal for outdoor use — MeltBlown Mat provides quick, efficient cleanup to help protect the environment from contamination.
- **Absorbs Oily Liquids — Repels Water:** MeltBlown polypropylene fibers are left in their natural hydrophobic state. These hydrophobic fibers repel water (and float) while only absorbing oils and other hydrocarbons.
- **High Sorbency Keeps Mat on the Job Longer:** Large-diameter MeltBlown polypropylene fibers are randomly assembled to create a lofty Mat that absorbs high volumes of liquid fast.
- **Bright White Color Makes it Easy to See When Mat is Completely Saturated:** Oily grunge can't hide on bright White MeltBlown Mat. Makes it easy to see when it's fully saturated — you save money by not throwing it away too soon.

WP100M Specifications

| | |
|------------------------|-----------------------------|
| Dimensions: | 15" W x 19" L |
| Shipping | 15" W x 19" L x 12.5" H |
| Dimensions: | |
| Sold as: | 100 pads per package |
| Color: | White |
| Composition: | Polypropylene |
| Absorbency: | Up to 26.7 gal. per package |
| Absorbency per: | Up to 34.18 oz. per pad |
| # per Pallet: | 36 |
| Basis Weight: | MediumWeight |
| Incinerable: | Yes |
| Ship Class: | 150 |

Metric Equivalent Specifications

| | |
|------------------------|--------------------------------|
| Dimensions: | 38.1cm W x 48.3cm L |
| Shipping | 38.1cm W x 48.3cm L x 31.8cm H |
| Dimensions: | |
| Absorbency: | Up to 101.1 L per package |
| Absorbency per: | Up to 1 L per pad |

WP100M Technical Information

Warnings & Restrictions:

There are no known warnings and restrictions for this product.

Regulations and Compliance:

49 CFR 173.3(c)(2) - The area between a container and a salvage drum used for overpacking must have "sufficient cushioning and absorption material to prevent excessive movement of the damaged package and to eliminate the presence of any free liquid at the time the salvage drum is closed."

40 CFR 263.31 - Transporters, "must clean up any hazardous waste discharge that occurs during transportation...so that the hazardous waste discharge no longer presents a hazard to human health or the environment."

40 CFR 263.30(a) - In the event of a spill, transporters must, "take appropriate immediate action to protect human health and the environment."

29 CFR 1910.22(a)(2) - Floors in your workplace should be, "maintained in a clean and, so far as possible, a dry condition."

29 CFR 1910.1450(e) - OSHA requires containment and cleanup materials for spills in laboratories to reduce occupational exposure to hazardous chemicals.

29 CFR 1910.120(j)(1) - Under an OSHA requirement, "DOT-specified salvage drums or containers and suitable quantities of proper absorbents shall be kept available and used in areas where spills, leaks, or ruptures may occur."

Technical Documents:

(Available at spilltech.com)

Product Data Sheet (PDS)

Material Safety Data Sheet (MSDS)



SpillTech

Online:
spilltech.com

Phone:
1-800-228-3877 (N.Am.)
1-770-475-3877 (Other)

Fax:
1-800-872-3764 (N.Am.)
1-770-410-1812 (Other)

Email:
spilltech@spilltech.com