



Hydrocide Xtreme

BRIDGEPOINT®
SYSTEMS

Fresh Fragrance Bonding and Encapsulating Deodorizer and Severe Odor Counteractant

Destroys odors in carpet, upholstery, mattresses and hard surfaces. HYDROCID™ Xtreme acts immediately and permanently against cat and other animal urine, vomit, decayed organic matter, sour smells, feces, skunk, musty mildew odors, and much more.



- Fresh fragrance bonding, absorbing, and encapsulating deodorizer and severe odor counteractant
- Eliminates odor on contact on carpet, upholstery, mattresses, and porous hard surfaces
- Effective against urine and feces odors, vomit, decay, skunk musk, and so much more
- Contains no oxidizers, enzymes, bacteria, or chemical desensitizers
- Fresh, green approved light fragrance that won't linger in the environment for weeks
- Works great with sub-surface extraction tools like the Water Claw™, Spot Lifter™, FlashXtractor™, and Flash Spotter™

Test for colorfastness. Always apply enough to assure direct contact with odor source. In some cases this means complete saturation.

As A Severe Odor Counteractant for Urine, Smoke, Vomit, and Feces: Add 4 to 8 ounces per gallon of water. Saturate spray or flood the treatment area with solution. It is important for the solution to come in direct contact with all of the odor affected surface. Allow to dwell for 5 to 10 minutes, then thoroughly blot or extract solution from treatment area. Any remaining odor is an indication that Hydrocide Xtreme™ did not come in direct contact with the odor source

For General Purpose Deodorization and Surface Treatment:

Add 8 ounces per gallon of water. Spray mixed solution onto treatment area. This solution may also be fogged using a wet fogger. Wear a NIOSH approved N95 organic vapor respirator, gloves and goggles when fogging the treatment area. For fogging, area must be vacated of pets and unprotected people for 30 minutes after treatment.

Upholstery, Mattress, and Pet Bed Treatment:

Add 8 ounces per gallon of water. Apply with trigger or hand held pressure sprayer to treatment area. Evenly apply the solution. Allow area to dry before using.

As a Carpet or Upholstery Cleaning Additive

For Presprays: Add up to eight ounces per gallon of ready to use prespray to deal with odors prior to

RTU pH: 6.5

cleaning. Be aware that the addition of Hydrocide Xtreme™ may neutralize some fragrances in presprays.

For Extraction Rinse Detergents: Add 1 to 2 ounces of solution to mixed concentrate of cleaning solution

As a Skunk Musk Treatment:

Add 8 ounces per gallon of water. Apply the solution thoroughly across the contaminated surface. Thoroughly agitate and brush the area. Blot up or vacuum away solution. Re-apply treatment solution to area and allow to dry. Do not extract, rinse, or blot up final solution application.

For Decaying or Decomposing Protein or Organic Matter:

Remove excess contamination. Add 8 ounces per gallon of water. Saturate spray or flood area with treatment solution. Agitate solution into contaminated area with brush. Allow to dwell 5 to 10 minutes. Extract area thoroughly. Re-apply treatment solution and allow to dry.

Special Directions When Using Water Claw Sub-Surface Extraction Tools (FlashSpotter™, Spot Lifter®, or FlashXtractor™) Saturate the area with Hydrocide Xtreme™ and flush area with the Water Claw by adding more water in the process. Follow up with a misting of the area with Hydrocide Xtreme™ and/ or Bridgepoint Bio-Modifier or Bio Charge.



Problem Solved.™

Quart - Part # CD17QT
Gallon - Part # CD17GL
Drum - Part # CD17DR

Bridgepoint Systems | 4282 South 590 West Salt Lake City, UT 84123

www.bridgepoint.com • (800)-658-5314

See Safety Data Sheet at www.bridgepoint.com/sds for safety and regulatory information.