

3-Way SRL

GUARDIAN
FALL PROTECTION

Part #	Length	Description
10974	50'	3-Way Rescue/Retrieval SRL
10981	65'	3-Way Rescue/Retrieval SRL

Compliant with all OSHA 1910, OSHA 1926 Subpart M, ANSI Z359.1-2007, and ANSI A10.32-2012 regulations.

Custom configurations not available. Contact customer service for details.

3-Way SRL is suitable for the following applications:



Personal Fall Arrest: 3-Way SRL may be used to support a MAXIMUM 1 Personal Fall Arrest System (PFAS) for use in Fall Arrest applications. Structure must withstand loads applied in the directions permitted by the system of at least 5,000 lbs. No free fall is permitted. Applicable D-ring: Dorsal.



Restraint: 3-Way SRL may be used in Restraint applications. Restraint systems prevent workers from reaching the leading edge of a fall hazard. Always account for fully deployed length of lanyard/SRL. Structure must withstand loads applied in the directions permitted by the system of at least 1,000 lbs. No free fall is permitted. Restraint systems may only be used on surfaces with slopes up to 4/12 (vertical/horizontal). Applicable D-rings: Dorsal, Chest, Side, Shoulder.



Rescue/Confined Space: 3-Way SRL may be used in Rescue/Confined Space applications. Rescue systems function to safely recover a worker from a confined location or after exposed to a fall. There are various configurations of Rescue systems depending on the type of rescue. Structure must withstand loads applied in the directions permitted by the system of at least 3,000 lbs. No free fall is permitted. Applicable D-rings: Dorsal, Chest, Shoulder.

For all applications: worker weight capacity range (including all clothing, tools, and equipment) is 130-310 lbs.

Materials: aluminum, copper, galvanized steel, and stainless steel.

Guardian Fall Protection recommends 3-Way SRL be used with a compatible tripod, such as the Guardian Arc-O-Pod (#15030, not included), and mounting bracket (#10983, not included). Contact Guardian Fall Protection with any questions regarding proper and compatible equipment configurations.

To activate rescue/retrieval mode, pull and hold Winch Locking Pin, and release Plunger Pin. To activate standard SRL mode, pull and hold Winch Locking Pin, compress Plunger Pin, and release Winch Locking Pin. Ensure Plunger Pin remains down and locked in place.

MAXIMUM 1 user per 3-Way SRL.

UPC-A Codes: 10974: 672421109749; 10981: 672421109817

